PulseGuide for Astro-Physics GTO Series Mounts

User Manual for Version 1.26 V1.04 – January 9 2004

Introduction	4
Software Licensing Agreement	5
Installation	7
Features	8
Changes/New Features	9
Version 1.26 – January 9, 2004	9
Version 1.25 – November 22, 2003	9
Version 1.21(Beta) – October 3, 2003	9
Version 1.20 – June 1, 2003	9
Version 1.10	9
Bugs Fixes	11
Version 1.26	11
Version 1.20	11
Version 1.10	11
Getting Started	12
Summary of Pages	15
Using a planetarium program with PulseGuide	17
Connect Page	18
Firmware Version	19
Help	19
l og Window	20
About	20
Additional Config options	21
Status Bar	23
Time Page	24
Time and Time Zone	24
Set Meridian Delay	25
Site Page	27
Get From Mount	27
Send to Mount	27
Save	28
Edit	28
Delete	28
Locations dat	28
Park/Rate Page	29
Tracking Rates	29
Delaved Stop or Park Mount	30
I Inparking the mount	31
Parking the mount	33
If you need to stop a park	34
Guide/Slew Page	35
Set Guide/Center Rate	35
Move Scone	25
Reorienting the Move Pushbuttons	36
Swanning Mount Move Directions	36
	00

STOP	37
Set Slew Rate	37
GOTO/Sync	37
Pulse Guider Page	38
Measure Rate Tool	38
Pulse Guiding4	40
Realtime Status4	42
Trouble Shooting 4	43
PGConfig Page 4	44
Use 0.25x Guide Rate up to 4	44
Use 0.50x Guide Rate up to 4	44
Use 1x Guide Rate up to 4	44
Use 12x Guide Rate up to 4	45
Max Pulses Per Second 4	45
Use Defaults 4	45
PEM/Other Page 4	46
Periodic Error Management 4	46
Focus Control4	47
Reticle 4	47
Backlash4	47
Backlash Tests 4	48
TPoint Page 5	53
TPoint Resynchronization – Step 1 5	53
TPoint Resynchronization – Step 2 5	54
Troubleshooting 5	55
PulseGuide won't connect and I know the COM Port is right 5	55
Appendix A – ASTRO-PHYSICS COMMAND PROTOCOL FOR GTO MOUNTS	
(Version "D" or "KD") 5	56
Appendix B – AP Commands by Category 6	32
Appendix C – AP Park Positions	35

Introduction

PulseGuide is a stand-alone Windows (98, ME, 2000, NT4, XP only) utility that provides complete remote control of <u>Astro-Physics</u> GTO400, GTO600, GTO900, and GTO1200 mounts. It derives its name from its most distinctive feature, *pulse guiding*, which can improve unguided tracking. Specifically it can help correct tracking errors caused by polar misalignment and refraction. You can also train **PulseGuide** to track objects moving relative to the stars, such as asteroids, comets, and the moon.

In addition to pulse guiding, *PulseGuide* also has many useful <u>utility</u> <u>features</u>. With just a few exceptions, it supports the entire serial Astro-Physics command protocol.

PulseGuide requires a serial connection from your PC to your mount using a straight through DB9 cable. One end of the cable must have a female connector and the other end male. Cables as long as 100 feet or more should work provided the cable is made from high-quality shielded cable. Cables with twisted pair wires work best, such as those from <u>Belden</u>.

PulseGuide for Astro-Physics GTO Series Mounts	
Connect Time Site Park/Rate Guide/Slew Pulse Guider	PG Config PEM/Other TPoint
Connection Connect	Firmware Version
Disconnect	E
Additional Config	
1200GT0	Help
Disable RA/Dec, Alt/Az Disable RA/Dec, Alt/Az Ask if OK to Exit Confirm GOTOs Always on top Confirm Syncs	Log Window
Ignore Mount Timeouts Display Alt/Az	About
RA = 01 57 03.6 Dec = +89 45 30 Side = East LST = 07	57 23 HA = +06 00 20

Figure 1

Software Licensing Agreement

The following statement must be read and agreed with before you can install this Software Product (*PulseGuide*).

IMPORTANT, PLEASE READ CAREFULLY: THIS IS A LEGAL AGREEMENT BETWEEN YOU AND SIRIUS-IMAGING (RAY GRALAK) BY INSTALLING, COPYING, OR OTHERWISE USING THE SOFTWARE PRODUCT, YOU ARE AGREEING UNCONDITIONALLY TO BE BOUND BY THE TERMS OF THIS LICENSE AGREEMENT, EVEN IF THIS LICENSE AGREEMENT IS DEEMED A MODIFICATION OF ANY PREVIOUS ARRANGEMENT OR CONTRACT. IF YOU DO NOT AGREE TO THE TERMS OF THIS LICENSE AGREEMENT, DO NOT INSTALL OR USE THE SOFTWARE PRODUCT.

1. For the purposes of this License Agreement, "Software", "Software Product", or "Software Patch" refers to the computer software and associated media, printed materials, and "online" or electronic documentation, including any and all executable files, tutorials, help files, utilities, and other files that accompany this product.

The Software Product is owned by Sirius-Imaging (Ray Gralak) and is protected by United States copyright laws, international copyright treaties, and all other applicable national laws. Title, ownership rights, and intellectual property rights in and to the software shall remain with Sirius-Imaging (Ray Gralak). The Software Product is licensed, not sold. There is no transfer to you of any title to or ownership of the Software, and this license shall not be construed as a sale of any right in the Software.

2. Other Restrictions. You may not reverse engineer, decompile, or disassemble the Software Product or make any attempt to discover the source code to the Software Product. Except as expressly permitted in this License Agreement or with written permission from Sirius-Imaging (Ray Gralak – ray@gralak.com), the Software may not be used, copied, redistributed, retransmitted, published, sold, rented, leased, marketed, sublicensed, assigned, transferred, altered, or modified.

3. Liability. BECAUSE THE SOFTWARE PRODUCT IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE SOFTWARE PRODUCT, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE SOFTWARE PRODUCT "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE SOFTWARE PRODUCT IS WITH YOU. SHOULD THE SOFTWARE PRODUCT PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE SOFTWARE PRODUCT AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE SOFTWARE PRODUCT (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE SOFTWARE PRODUCT TO OPERATE WITH ANY OTHER SOFTWARE PRODUCTS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

I have read and agree to the terms of the license agreement as set forth above.

Installation

After downloading the latest version of **PulseGuide** from the <u>PulseGuide</u> <u>Home Page</u>, you will need to unzip it to get to the setup EXE that is usually named **PulseGuideVVV.EXE**, where "VVV" is the version number. For example, version 1.26's install EXE is **PulseGuide126.EXE**.

The installation is very straightforward. Follow the install directions to complete the installation. After the installation completes a new program group, "Pulse Guide", will be available with links to run **PulseGuide** and to view documentation, etc. The installation will also automatically try to add an icon to the desktop.

Features

- Fully supports the <u>AP serial command protocol</u>.
- <u>Pulse guiding</u> This corrects for drift due to mispolar alignment and refraction. Pulse guiding is an idea originally suggested by Roland Christen (founder of Astro-Physics) and implemented in this application. It works by sending precisely timed serial commands that make the mount move faster in RA and/or Dec for a short period (hence "pulses").
- Declination axis tests that you can use to check the health of your mount's declination axis.
- With one button <u>Unpark</u>, automatically setting the time, time zone, longitude, and latitude without ever needing to plug in the hand controller. **PulseGuide** will even detect that your mount is not initialized and ask to initialize it.
- Unpark from one of the AP park positions or your own Alt/Az
- One-button Park feature allows you to park the mount at its current position, one of the AP park positions, or a user-defined Alt/Az.
- Set <u>guide</u>/<u>slew</u> rates.
- Buttons to <u>move</u> the scope conveniently.
- A <u>status bar</u> that shows the scope's position in RA/Dec (or Alt/Az), the side of mount that the scope is on, Local Sidereal time, and Object Hour Angle.
- <u>Set the tracking rate</u> (sidereal, lunar, solar, zero).
- <u>Delayed stop or park</u> of the mount so the scope will not hit the pier if you fall asleep or forget to shut down the scope.
- <u>PEM</u> (On/Off, record with timer).
- Set mount to <u>PC Time and set Time Zone</u>.
- <u>Set a Meridian delay</u> so the mount will not flip on a GOTO command.
- Convenient <u>Site management</u>.
- <u>GOTO/Sync</u> to RA/DEC coordinates. <u>STOP</u> button to stop a GOTO, if desired.
- <u>TPoint resynchronization</u>. This is a useful tool if you are using Software Bisque's TheSky with a TPoint model and lose synchronization because you moved the scope by hand.
- <u>Focus control</u> including a counter to keep track of position.
- Reticle brightness control.
- Set mount backlash.
- Other miscellaneous features.

Changes/New Features

Version 1.26 – January 9, 2004

None – bug fixes only.

Version 1.25 – November 22, 2003

- 1. Added a third Declination axis test. To do this test you must remove the declination axis cover and watch the gear train. Or, you can observe the motion at night by looking at a star with very high power.
- 2. The focuser control now has a position counter. When a button is pressed the focuser will be sent pulses slowly at first and will accelerate as you keep the button pressed.

Version 1.21(Beta) – October 3, 2003

- 1. A new comprehensive mount initialization dialog automatically pops up when the mount is detected in the un-initialized state after power is applied.
- 2. Added two Declination-axis backlash tests suggested by Roland to determine the health of your mount's declination axis.

Version 1.20 – June 1, 2003

- 1. Improved internal logic to prevent commands from overlapping.
- 2. Additional movement buttons, ability to rotate buttons.
- 3. New Measurement results dialog.
- 4. Park to AP Park Positions or user-defined Alt/Az.
- 5. Unpark from AP Park Positions or user-defined Alt/Az.
- 6. Improved accuracy when setting and retrieving time.
- 7. Focus control.
- 8. Reticle brightness control.
- 9. Backlash control.
- 10. Local serial time displayed in status bar (instead of sidereal time).
- 11. Numerous minor user interface changes.

Version 1.10

1. New status bar on the bottom of the window displays RA, DEC, Side of mount the scope is on, the current sidereal time, and the hour angle (angle of the scope relative to the meridian). The status bar is not part of any of **PulseGuide**'s tabs so it displays all time while the mount is connected.

2. Optionally, the **PulseGuide** application will place itself always on top of other windows.

3. New Locations tab allows user to save and restore an arbitrary number of locations (longitude/latitude). *PulseGuide* can easily send whichever location you choose to the mount.

4. New TPoint tab allows you to resynchronize your mount to your TPoint(TM) Model in TheSky(TM).

5. In addition to stopping the mount the Delayed Stop feature can now Park the mount. Parking de-energizes the motors so that autoguider signals or serial commands will not move the mount.

6. When unparking the mount the mount's longitude, latitude, and time zone are sent in addition to the PC time.

7. You can swap the positions of the N/S and E/W move scope buttons.

8. Goto manually entered coordinates.

9. Sync to manually entered coordinates

10. STOP movement button to stop a GOTO if necessary

11. When one of the Set Guide/Centering Rate buttons is pressed the rate is now displayed in the center of the Move Scope buttons (in addition to the Last Sent edit box).

12. **PulseGuide** now updates RA and Dec every second instead of every other second.

13. Removed the ALT/AZ option (tell me if you want it back in).

14. Other miscellaneous changes.

Bugs Fixes

Version 1.26

- 1. Fixed Dec Test 3 which would only do one movement to the North before reversing to the South.
- 2. Fixed the focuser counter. It now decrements the counter when you press the "-" button.

Version 1.20

1. The Measure Rate Tool now calculates the RA and Dec rates correctly.

2. The serial commands are now queued so they cannot overlap each other. Stricter error checking is done on responses.

3. PulseGuide no longer disconnects often.

4. Hour-Angle in status bar is now correct.

Version 1.10

Unpark now sends location and time zone in addition to time (which was all that **PulseGuide** sent in v1.10). In particular, this is what **PulseGuide** sends when you click Unpark (commands sent in this order):

Longitude Latitude Local Time Time Zone Date Unpark command Set Sidereal Rate

Getting Started

After starting **PulseGuide** but before connecting to the mount you will need to connect a serial cable to the mount and determine which COM port to select.

PulseGuide requires a serial connection from your PC to your mount using a straight through DB9 cable. One end of the cable must have a female connector and the other end male. Cables as long as 100 feet or more should work provided the cable is made from high-quality shielded cable. Cables with twisted pair wires work best, such as those from <u>Belden</u>.

Connect the male end of the serial cable to one of the two serial ports on your mount. It does not matter which you use. Once connected, you can start **PulseGuide** from its desktop icon or from the Start menu. You should see something like the following Figure:

PulseGuide for Astro-Physics GTO Series Mounts	
Connect	
Connection	Firmware
COM2 Connect	Version
Disconnec	t
Additional Config	
1200GT0	Help
□ Disable RA/Dec, A □ Ask if OK to Exit Confirm GOTOs	lt/Az Log Window
Always on top Confirm Syncs	About
I gnore mount Timeouts J Display Alt/Az	About

Figure 2 – Before connecting

Next, you must select the appropriate COM port. If you are using a desktop or notebook PC with a single serial port it is likely that it is COM1. Desktop PC's with two serial ports usually are COM1 and COM2. If you are using a USB to serial port adapter, such as the Iogear <u>GUC232A</u> you can find out in the Windows Device Manager which COM port it is using.

If you are still unsure of the COM port then make sure that **"Ignore Mount Timeouts**" is unchecked then start trying COM ports starting with COM1. If a port is invalid or opened by another application **PulseGuide** will report an error opening the port, or no will succeed.

Once connected a number of additional page tabs appear. If the port is really communicating to the mount the status bar will fill with the RA, DEC, side of mount, etc., like this:

PulseGuide for Astro-Physics GTO Series Mounts	
Connect Time Site Park/Rate Guide/Slew Pulse Guider	PG Config PEM/Other TPoint
Connection	Firmware
COM2 Connect	Version
Disconnect	E
Additional Config	
12005T0	Help
Ask if OK to Exit Ask if OK to Exit Always on top	Log Window
Ignore Mount Timeouts Display Alt/Az	About
RA = 01 57 03.6 Dec = +89 45 30 Side = East LST = 07	57 23 HA = +06 00 20

Figure 3 – Successful connection

If PulseGuide detects that the mount is in the powered up and unparked state (RA=0, Dec=90) it will automatically pop up the Initialization dialog shown below. From this dialog you can set up and review which parameters PulseGuide will immediately configure.

Supported parameters are unpark position, Site, Time Zone, Tracking Rate, Guide Rate, Slew Rate, Dec and RA backlash, and PEM enable.

All parameters that you set will be remembered and displayed in this dialog the next time this dialog displays (which will be the next time you power up the mount).

PulseGuide Mount Initialization	n Dialog 🛛 🗙
Your mount is not yet initialized. Y can initialize and unpark now (or la from the Park/Rate Page).	ou Initialize ater Cancel
Unpark: From Last Parked Position	
Site: Home	•
Time Zone: 7 Hours	0 Mins
🔽 Set Tracking Rate	Sidereal 💌
🔽 Set Guide/Centering Rate	1x 💌
🔽 Set Slew Rate	1200x 💌
🔽 Set Dec Backlash	0 Arc Secs
🔽 Set RA Backlash	0 Arc Secs
Enable PEM	

Click **Initialize** to automatically initialize the mount. If you decide to click **No** you can always initialize the mount later by <u>unparking</u> it.

If you have not set up a default <u>site</u> yet, you will get this dialog:

PulseGuid	le 🛛 🕹
1	WARNING: You have not set up a default site on PulseGuide's Park Page so using Mount's last used Long/Lat. Are you sure you want to initialize at this time?
	OK Cancel

PulseGuider v1.26 User Guide and Manual v1.04 – Copyright © 2003/4 Ray Gralak

Despite this warning it is usually OK to click **OK** if you know that the last used location of the mount was set properly (from either the keypad or from a planetarium program or **PulseGuide**).

Summary of Pages

Here is a summary of what each page does. For more information on a page, click the link:

<u>Connect Page</u> – The initial page with connect options. The firmware version will display here when connected. You can click the **Help** button to get program help. You can also access help for any page by pressing **F1** with that page displayed.

<u>Time Page</u> – You can set or get your mount's time and time zone. You can also set a <u>simulated meridian delay</u> on this page.

<u>Site Page</u> – You can define the longitude and latitude of sites you visit. You can also get the longitude and latitude currently set in your mount. The sites you define on this page can be set up automatically when you unpark your mount in the <u>Park/Rate Page</u>.

Park/Rate Page – You can set your tracking rate with one of the built-in rates the mount supports (sidereal, lunar, solar, zero).

You can also do a one-button unpark and park of your mount. When parking, you can have your mount slew to one of the <u>AP Park Positions</u> or an Alt/Az of your choice.

Lastly, you can set up a delayed stop of your mount when imaging. This will stop the mount after a number of hours so that your mount will not hit the pier if you fall asleep or forget to stop it.

<u>Guide/Slew Page</u> – You can set the mount's guide, centering, and slew rates. You can move the mount around with buttons. You can do a GOTO to a RA/Dec coordinate or SYNCH on a RA/Dec coordinate.

<u>Pulse Guider Page</u> – You can use the pulse-guiding feature from this page.

<u>PG Config Page</u> – You can adjust the pulse-guiding configuration parameters from this page.

<u>PEM/Other Page</u> – You can record a periodic error (PEM) cycle, turn on and off PEM, control focus through the AP focus port, adjust reticle brightness, and set RA and Dec backlash.

<u>TPoint Page</u> – This page allows you to resynchronize with your Software Bisque TPoint model, should you accidentally move your scope by hand or otherwise loose synchronization.

Using a planetarium program with PulseGuide

You have two choices to allow you to use **PulseGuide** and a planetarium program such as TheSky, MegaStar, Desktop Universe, etc.

- You can use the second serial port on your mount and a second COM port on your PC. This provides dedicated connections for both applications so you can use both *PulseGuide* and your planetarium program simultaneously. However this obviously requires two serial cables and COM ports on your PC, which might not be available.
- 2. You can use a single serial cable and connect to each program when needed then disconnect when done.

I am looking into a couple other solutions that will require only a single cable yet allow both applications simultaneously connected. I will announce solutions as they become available on the <u>AP GTO Users</u> <u>Group Mailing List</u>.

Connect Page

Figure 4 below shows **PulseGuide** as it comes up. If this is your first time using **PulseGuide** please also take a look at the <u>Getting Started</u> section. In order to control your Astro-Physics GTO mount you must have a serial port connection (or USB to serial adapter) to your mount. For most PC's and laptops you will need to connect a "straight through" DB9 to DB9 Male to Female cable.

All Astro-Physics GTO mounts have two serial ports so if you also need to control your mount with TheSky or other planetarium software then you will need a second serial port on your PC and another cable. Again, you can use a USB to serial adapter if your PC does not have a second serial port. Iogear makes one that works well for me (<u>GUC232A</u>).

PulseGuide for Astro-Physics GTO Series Mounts	
Connect	
Connection Connect	Firmware Version
Disconnect	
Additional Config	
Ask if OK to Exit Confirm GOTOs	Log Window
☐ Ignore Mount Timeouts ☐ Display Alt/Az	About

Figure 4

Once you have connected your PC to the mount you need to select the serial port that you are using. If you have only one serial port then the port is likely COM1. If you have two ports then they are probably COM1 and COM2. If in doubt, start with COM1 and increase the port number sequentially.

When testing a port for the first time, make sure to uncheck the checkbox **Ignore Mount Timeouts**. *PulseGuide* will report an error if the mount does not respond.

If the mount does respond, the Firmware version will display and **PulseGuide** will fill the status bar with information as shown in figure 5:

PulseGuide for Astro-Physics GTO Series Mounts	
Connect Time Site Park/Rate Guide/Slew Pulse Guider	PG Config PEM/Other TPoint
Connection	- Firmware
COM2 Connect	Version
Disconnect	E
Additional Config	
1200510	Help
Disable RA/Dec, Alt/Az	Log Window
Always on top	
🔲 Ignore Mount Timeouts 📄 Display Alt/Az	About
RA = 01 57 03.6 Dec = +89 45 30 Side = East LST = 07	57 23 HA = +06 00 20

Figure 5

However, if the mount does not respond then **PulseGuide** will automatically disconnect in about 15 seconds. If this happens, check your cable and/or try another serial port until you have found the correct port.

Firmware Version

The latest firmware available for general distribution as of May 2003 is version "D" or "KD". I happen to have a prototype of version "E" installed but it is essentially no different in functionality than version D/KD.

Help

Pressing this button brings up help. Internet Explorer 4 or later must be installed for help to work. You can also press **F1** to activate help for the specific page that you are on.

Log Window

Pressing the **Log Window** button will open the Command Log window. This may be useful in debugging communications to your mount.

Commands sent to the mount are in **green** and replies from the mount are in **blue**. If a command times out a message will display in **red**.

The decimal number at the start of each line is the relative time in seconds since the first command was printed. The time is in seconds and is accurate to the nearest millisecond.

PulseGuide - Command Log	
PulseGuide - Command Log 14.140 SND: 'GD#' 14.156: RCV: '+89*45.3' 14.171: RCV: '0#' 15.109 SND: 'GR#' 15.125: RCV: '03:48:52' 15.140: RCV: '.3#' 15.156: RCV: '489*45:3' 15.171: RCV: '0#' 16.109 SND: 'GR#' 16.125: RCV: '03:48:53.3#' 16.125 SND: 'GD#' 16.156: RCV: '489*45:30#' 17.109 SND: 'GR#' 17.125: RCV: '03:48:54' 17.125: RCV: '03:48:54' 17.125: RCV: '3#' 17.125: RCV: '3#' 17.156: RCV: '489*45:30#' 18.109 SND: 'GR#' 18.125: RCV: '189*45:30#' 18.125: RCV: '348:55' 18.140: RCV: '3#' 18.156: RCV: '489*45:3' 18.171: RCV: '0#' 18.156: RCV: '489*45:3' 18.171: RCV: '0#' 19.109 SND: 'GR#' 19.125: RCV: '03:48:56'	
19.140: RCV: '.3#' 19.140 SND: ':GD#' 19.156: RCV: '+89*45:30#'	
1	_
Close	

About

Click the **About** button to open the dialog to see the version of **PulseGuide**.

Additional Config options

The mount type selection does not do anything at the moment but I intend to use it to set a countdown timer in the PEM page.

PulseGuide for Astro-Physics GTO Series Mounts	
Connect Time Site Park/Rate Guide/Slew Pulse Guider	PG Config PEM/Other TPoint
COM2 Connect	Firmware Version
Disconnect	E
Additional Config	
1200GT0	Help
Disable RA/Dec, Alt/Az Disable RA/Dec, Alt/Az Alt/Az Alt/Az Alt/Az Alt/Az Confirm GOTOs Alt/Az Confirm Syncs	Log Window
🔲 Ignore Mount Timeouts 🛛 Display Alt/Az	About
RA = 01 57 03.6 Dec = +89 45 30 Side = East LST = 07	57 23 HA = +06 00 20

Ask if OK to Exit: If this option is checked then **PulseGuide** will ask if you really wanted to exit the application when you close it. This may prevent you from accidentally closing **PulseGuide** when you did not mean to.

Always on top: If this option is checked then **PulseGuide** will attempt to keep itself on top of all other windows.

Ignore Mount Timeouts: If checked if the mount does not respond then **PulseGuide** will not automatically disconnect. This option is useful when becoming familiar with **PulseGuide** without actually connecting to your mount.

If you are having communication difficulties you may also want to check this option. You

Note: This option is grayed and cannot be changed when connected to the mount. If you need to change it, disconnect first, change it, and then reconnect.

Disable RA/Dec, Alt/Az: If selected this option will stop **PulseGuide** from querying the mount for RA/Dec and Alt/Az. Typically you will leave this unchecked but sometimes when debugging the other features with the log window enabled it is easier to see the commands you are interested in.

Confirm GOTOs: If selected a dialog will pop up whenever you click the GOTO button in the Guide/Slew Page.

Confirm Syncs: If selected a dialog will pop up whenever you click the SYNC button in the Guide/Slew Page.

Display Alt/Az: If selected Altitude and Azimuth will display in the status bar instead of RA/Dec. PulseGuide still queries for RA/Dec because some of the other features need it (like the hour-angle in the status bar).

Status Bar

When connected a status bar with 5 panes appears in the bottom of **PulseGuide**. Here is the description of each pane:

RA = 03 08 28.8 Dec = +89 45 30 Side = East LST = 09 08 50 HA = +06 00 21

RA: This field shows the current Right Ascension of the mount. *PulseGuide* updates this field once a second.

Dec: This field shows the current Declination of the mount. *PulseGuide* updates this field once a second.

Side: This is the side of the mount the telescope is on as reported by the mount. The actual side may be different if you set a <u>meridian delay</u> in the <u>Time Page</u>. *PulseGuide* updates this field once a minute.

LST: This is the local sidereal time, which is obtained by adding the time zone to the sidereal time received from the mount. *PulseGuide* queries the mount once a minute for this parameter but automatically increments the time every second.

HA: This is the *hour angle* of the telescope, which is the angle from the meridian. A negative value tells how many hours, minutes, and seconds before the scope crosses the meridian. A positive value indicates how long ago the current object passed the meridian.

Time Page

Figure 3 Shows the Time Page. Whenever you enter this page **PulseGuide** sends a command to the mount to get its time and time zone offset. While this page is active **PulseGuide** simply increments the mount's time once per second without querying the mount again. If you wish to get the mount's time again then simply click another page and then go back to this page.

🕈 PulseGuide for Astro-Physics GTO Series Mounts
Connect Time Site Park/Rate Guide/Slew Pulse Guider PG Config PEM/Other TPoint
Time
Set Time to PC Time Mount Time 20:25:46.7
Set Time Zone Offset Time Zone 07:00:00.0
Hours Mins Fill TZ Offset from mount Time Zone Offset: 7 0
Simulated Meridian Delay
Set Meridian Delay Meridian delay (Hours) -1
RA = 05 35 05.9 Dec = +89 45 30 Side = East LST = 11 35 28 HA = +06 00 22

Figure 6

Time and Time Zone

You can set the mount to the PC by clicking the **Set Time to PC Time** button. Similarly, clicking the **Set Time Zone Offset** button will set the time zone offset to the hours and minutes you enter.

Fill TZ Offset: When this is checked the Set Time Zone Offset hours and minutes fields will be filled in with the time zone offset received from the mount. *PulseGuide* queries the mount for time zone offset each time you enter this page.

Set Meridian Delay

PulseGuide supports a simulated meridian delay feature by adding an offset to the mount's time. For example, if the time is really 10PM and you press **Set Meridian Delay** with a meridian delay of -1 hours then **PulseGuide** will set the time to 9PM even though it is really 10PM.

The time change affects which side of the mount will put the scope on when you issue a GOTO command. If you specify meridian offset = 0 and you issue a GOTO to a star that is east of the meridian then the mount will place the scope on the right side of the mount. A GOTO to a star west of the meridian will place the scope on the east side of the mount.

A positive Meridian Delay will simulate all objects being farther west than they really are. This will cause the mount to flip the scope to the east side of the mount (on a GOTO command) before the object reaches the meridian.

This allows you to track an object across the meridian until well after the meridian without risk of the scope hitting the pier. You can also use the <u>Delayed Stop</u> <u>feature</u> for additional safety.



Positive Meridian Delay Allows This on GOTO

A negative Meridian Delay value will simulate all objects being farther east than they really are. This will cause the mount to flip the scope to the west side of the mount (on a GOTO command) for after an object reaches the meridian.



Negative Meridian Delay Allows This on GOTO

WARNING: Use the Meridian Delay feature with caution. If you issue a GOTO to the wrong coordinates, you could cause the scope to collide with the pier.

Site Page

Here you can manage your sites. A *site* is defined by it's name and includes a longitude and latitude. You can also retrieve and set the longitude and latitude of the mount.

PulseGuide for Astro-Physics GTO Series Mounts				
Connect Time Site Park/Rate Guide/Slew Pulse Guider PG Config PEM/Other TPoint				
Site Longitude and Latitude				
Get from Mount Site Name: Got Long/Lat OK	Save			
Send to Mount Longitude: W 💌 121 51	5 Edit			
Latitude: N 💌 37 24	43 Delete			
Site Name Longitude	Latitude			
Home W 121 51 05	N 37 24 43			
J				
RA = 09 03 38.9 Dec = +00 07 29 Side = West LST = 03 04 0	IO HA = -05 59 39			

Get From Mount

Clicking this button will send commands to the mount to return the current longitude/latitude of the mount. The longitude and latitude returned from the mount will be placed in the appropriate fields. If the mount returned the values OK then the **Site Name** field will be filled with "**Got Long/Lat OK**".

Send to Mount

Clicking this button will send the displayed longitude and latitude to the mount. You can double-click any Site in the table below to load it into the Location, Longitude, and Latitude fields. Alternatively, you can single-click a site in the table and press the **Edit** button to load that site.

Save

Clicking this button will place the site into the table below and into a disk database file, *Locations.dat*, which is in the install/run directory).

New sites are saved based on the name of the site. That is if you modify just the longitude and/or latitude for a site and click **Save** then the current site will be modified. However, if you change the site name and click **Save** a new site will be created and saved.

Edit

This button activates when you select (click on) a site in the site name table. Pressing it will load the site for you to edit. A shortcut for selecting and pressing edit is to double-click the site in the table.

Delete

This button activates when you select (click on) a site in the site name table. Pressing it will delete the selected site. You can only delete one site at a time and there is no confirmation before deleting so make sure before you click!

Locations.dat

Note: Do not try to edit the text database (**Locations.dat**) by hand because it uses fixed fields that might be easy to change with human editing!

Park/Rate Page

From this page you can set the tracking rate, park and unpark your mount and set up a "delayed stop" of your mount.

🛉 PulseGuide for Astro-Physics GTO Series Mounts			
Connect Time Site Park/Rate Guide/Slew	Pulse Guider PG Config PEM/Other TPoint		
Tracking Rate Sidereal Solar Lunar Zero Last Sent:	Unpark/Park Unpark From Last Parked When unparking use this Site's Long/Lat: Home		
Delayed Stop or Park Mount Hours Mins Secs Stop Mount 0 0 0 0	Hours Park Slew East first: 1 Goto AP park position 3 then Park Alt Az User Park Position: 3 23		
RA = 12 19 47.5 Dec = +00 07 29 Side = Wes	st LST = 06 20 10 HA = -05 59 37		

Tracking Rates

All of the AP GTO mounts have four standard tracking rates. Use **Sidereal** when tracking fixed RA/DEC objects, **Solar** when tracking the sun, **Lunar** when tracking the moon, and **Zero** when looking at a fixed terrestrial object or to stop the mount from moving (without parking).

When you press one of these buttons, the **Last Sent** field will be filled with the rate that you select. However, the displayed rate may not be valid later if you disconnect, park, unpark, select rates from the keypad, or power cycle the mount.

Delayed Stop or Park Mount

You can use this feature to stop your mount automatically in case you forget or fall asleep during an imaging session. It works with the use of a timer that counts down to zero. When it decrements to zero the mount is stopped or parked.



Stopping the mount sets the rate to zero (same as pressing the **Zero** button in the <u>Tracking Rates</u> section). You can still use the buttons to move the scope. Parking not only stops the mount, it also de-energizes the motors.

If you have an autoguider connected to the mount then I recommend parking the mount in case the autoguider tries to keep on tracking. If you just stop the mount the autoguider may keep sending signals to move the mount further even though the rate is zero.

Note: While a delayed stop/park countdown is in progress, you cannot disconnect from the mount or exit **PulseGuide**.

WARNING: BE CAREFUL IF YOU USE THIS FEATURE! You may risk a mount collision if you calculate the wrong time, your PC crashes, or you disconnect the serial cable. This feature has been tested well and it has worked without fail, however it is entirely your responsibility to prevent damage to your equipment. I recommend you keep your RA clutches on the loose side (but not too loose) so the mount will gently slip if the scope comes to rest on the mount.

Unparking the mount

PulseGuide has a one-button unpark feature that sends all necessary information to the mount to initialize it without the keypad. You cannot unpark from the last parked position if the mount is already initialized because a second unpark will reset the RA and Dec to what they are at the last parked position and your mount will no longer be pointing correctly.

When you first connect to the mount if PulseGuide detects that the mount is at RA=0 Dec=90 or Dec=-90 (the uninitialized position) it will ask if you want to initialize the mount (see <u>Getting Started</u> section).

If you have moved your scope and don't remember where you parked it last then you can also unpark from one of the three <u>AP park positions</u> or your own ALT/AZ. However, you should always unpark **From Last Parked** if you have not moved your mount between imaging sessions.

- Unpark/Park		
Unpark	From Last Parked 💌	
When unparking use this Site's Long/Lat:		
Home	•	

Before unparking you should also set the site to use. If you have not set this up yet you can do so in the <u>Site Page</u>. If you have not changed sites from the last time the mount was unparked it is ok to not select a site (although it won't hurt to select one)

Clicking the **Unpark** button will initialize the mount with the following information:

(clears buffers) :U# (sets high precision mode) Longitude (if you have a site selected) Latitude (if you have a site selected) Local Time Time Zone Date Unpark command Set Sidereal Rate

PulseGuide uses the current PC time and the time zone that is set on the <u>Time Page</u>, and the longitude and latitude of the site selected in the

drop down list box. Additionally **PulseGuide** sends a command to set the tracking rate to Sidereal in case it was set otherwise. The list box's first entry is an option not to send the long/lat to the mount. Other entries in the list box are from entries in the table in the <u>Site Page</u>.

Parking the mount

Parking stops the mount completely and de-energizes the motors. If power is maintained to the mount, RA and Dec are still calculated when queried, but RA will change as the mount will not move.

PulseGuide has a one-button unpark feature that can park the mount in the current position, one of the three <u>AP Park Positions</u>, or a user defined ALT/AZ position. There is also an option to slew east a number of hours before doing the park.

	Hours
Park 🗖 Slew E	last first: 1
Goto AP park position	3 then Park 📃
	_AltAz
User Park Position:	3 23

First, select the position to park in. There are five choices:

Park at current position – Parks the mount exactly where it is (unless **Slew East First** is checked).

Goto AP park position 1 then Park – Slews to park position 1 then parks.

Goto AP park position 2 then Park – Slews to park position 2 then parks.

Goto AP park position 3 then Park – Slews to park position 3 then parks.

Goto user-defined Alt/Az then Park – Slews to the ALT/Az defined in **User Park Position**.

Slew East First: Sometimes when imaging a southerly object across the meridian the telescope may start to pass under the north side of the mount. I have found that if this happens and you do a park to <u>AP Park</u> <u>Position 3</u> the scope could hit the pier as the mount tries to orient the scope north.

To prevent this from happening select this option and set the number of hours to whatever you think is necessary. 6 hours equals one quarter rotation of the mount's RA axis.

When you click **Park**, *PulseGuide* will ask for confirmation before proceeding. Once started *PulseGuide* will send the PC's current time just in case a <u>meridian delay</u> had been in use. It will then slew east if that option is selected. Next, it will do a GOTO the park position, again if that option is selected. Lastly, it will send the mount park command.

If you need to stop a park

Once a park begins the label of the **Park** button changes to **Stop.** Pressing this button will immediately stop the park including an active slew or GOTO.

STOP Park	Hours
Goto AP park position	1 then Park 📃 💌
	Alt Az
User Park Position:	3 23

Note 1: While a park is in progress, you cannot disconnect from the mount or exit *PulseGuide*.

Note 2: According to Astro-Physics, after parking you should power off the mount. While parked DO NOT MOVE THE MOUNT with the keypad or via **PulseGuide's** controls or the mount's position could be wrong the next time you unpark.

Guide/Slew Page

Figure 6 shows the Guide/Slew Page. Here you can set the slew and guide rates, move the scope with buttons, and perform a GOTO or SYNC on a manually entered RA and Dec.

🕈 PulseGuide for Astro-Physics GTO Series Mounts				
Connect Time Site Park/Rate Guide/Slew Pulse Guider PG Config PEM/Other TPoint				
Set Guide/Centering Rate	Move Scope (while button is pressed)			
0.25x 1x 12x 600x	NE N NW Rotate 90			
0.50x 64x 1200x	E W Swap E/W			
Last Sent:	SE S SW STOP			
Set Slew Rate	Goto/Sync-			
600x 900x 1200x	Go To RA: 23 1 2			
Last Sent:	Sync Dec: 30 4 5			
RA = 12 52 44.4 Dec = +52 35 14 Side = East LST = 00 51 35 HA = +11 58 51				

Set Guide/Center Rate

Press the appropriate button to set the rate that the mount will move the scope when you press the buttons in the <u>Move Scope</u> area of this page. When you press one of the rate buttons the rate is saved as a reminder in the **Last Saved** edit box. This rate is also displayed in the center of the move buttons on this page and on the <u>Pulse Guider page</u>.

Move Scope

The buttons here allow you to move the scope in the indicated direction. The scope only moves when a button is pressed. The RA and Dec in the status bar will update once per second unless you have disabled it on the <u>connect page</u>. If you pressed a

NE	N	NW
E	0.25x	W
SE	S	SW

<u>guide/center rate button</u> then the rate will be displayed in the center of the buttons as shown in the picture to the upper right.

PulseGuider v1.26 User Guide and Manual v1.04 – Copyright © 2003/4 Ray Gralak

Reorienting the Move Pushbuttons

If you choose, you can reorient the buttons with the checkboxes to the right of the move pushbuttons. This is useful when you are imaging and want to orient button presses with your downloaded images. This only works well if you orient your camera roughly to the RA and Dec axes.

Rotate 90: Setting this checkbox will rotate the buttons 90 degrees clockwise.

Swap N/S: Setting this checkbox (not the <u>button</u>) will swap the positions of the **NE-N-NW and SE-S-SW** buttons.

Swap E/W: Setting this checkbox (not the <u>button</u>) will swap the positions of the NE-E-SE and NW-W-SW buttons.

Swapping Mount Move Directions

Swap N/S: Pressing this button (not the <u>checkbox</u>) will Swap N/S send a command to the mount to swap North and South directions when doing a button press or serial control commands. This may be needed when the mount flips sides. Now while watching the status bar Dec should increase when you press N (north) if the orientation is correct. If it does not click this button to swap N/S.

Note that pressing this button does not reorient any of the button positions.

Swap E/W: Pressing this button (not the checkbox) will Swap E/W send a command to the mount to swap North and South directions when doing a button press or serial control commands. Normally you will not need to do this. You can check that your mount is configured properly by first selecting 64X speed in the Guide rate section so the RA will change relatively rapidly. Now while watching the status bar RA should increase when you press **E** (east) if the orientation is correct. If it does not click this button to swap E/W.

Note that pressing this button does not reorient any of the button positions.

Swap N/S Swap E/W STOP

Rotate 90

STOP

You should only ever need to press the **STOP** button to stop a GOTO in progress.

Set Slew Rate

Press these buttons to change the slew rate of the telescope, which is the rate the scope moves the scope (as a factor of sidereal rate) when doing a GOTO. When you press one of the rate buttons the **Last Saved** edit box will show the rate you selected as a reminder.

GOTO/Sync

GOTO: Pressing this button will issue a command to the mount to GOTO the coordinates you set in the RA and Dec edit boxes. RA is in hours, minutes, and seconds. Declination is in degrees, minutes, and seconds. If you select **Confirm GOTOs** on the <u>Connect page</u> then **PulseGuide** will prompt you before doing the GOTO.

Sync: Pressing this button will synchronize the mount to the RA and DEC coordinates in the edit box. Typically, a star or object with known RA/DEC coordinates is centered visually or with a CCD camera and then the object's coordinates entered in the edit box and the **Sync** button pressed. Most Planetarium programs have this feature but it is here for completeness. If you select **Confirm Syncs** on the <u>Connect page</u> then **PulseGuide** will prompt you before doing the sync.

Pulse Guider Page

Pulse guiding is a method that can change, subtly or dramatically, the tracking rate of your mount. Roland Christen suggested this technique, which consists of precisely timed commands that emulate move the mount at the guide rate speed. The changes are so small and happen so quickly that they appear to smoothly change the tracking rate.

PulseGuide for Astro-Physics GTO Series Mounts			
Connect Time Site Park/Rate Guide/Slew Pulse Gui	der PG Config PEM/Other TPoint		
Pulse Guiding	Measure Rate Tool		
RA ArcSec/Sec 0.8 ± 0.77810 0n	Start Stop		
Dec ArcSec/Sec 0.8 ± 0.78150 Off	Time 20 Secs		
Pulse Guide Rate: 1.00 x	dRA 0.76531 "/S		
Realtime Status	dDec 0.76531 "/S		
HA Dec Pulse On: 723 mSecs 91 mSecs	NE N NW		
Pulse Off: 277 mSecs 909 mSecs	E 64x ₩		
Pulses: 43 (1.08/sec) 43 (1.08/sec)	SE S SW		
RA = 08 29 53.2 Dec = +89 52 15 Side = East LST =	14 30 38 HA = +06 00 46		

This page is divided into three main sections. In the **Pulse Guiding** section you enter the rate that you wish to set and turn pulse guiding on and off. In the **Realtime Status** section information about pulses widths and counts is displayed. The **Measure Rate Tool** section allows you to measure the motion of a star, asteroid, comet, moon, etc. then immediately use the rate.

Measure Rate Tool

To use the pulse guiding feature you must enter a known rate or directly measure it. Unfortunately, even with a known rate of, say, an asteroid, it is unlikely that just entering that rate will allow perfect tracking because the mount itself is not tracking celestial objects precisely because of the effects of refraction and slight polar misalignment.

So to get accurate tracking you need to measure the "tracking imperfection" an object for a period of time. You can do this in a couple of ways. One way is to center a star visually with a crosshair eyepiece or with a CCD camera. Then press the **Start** button in the Measure Rate section (see picture to the right). It is best to wait for an exact multiple of the worm gear period (628 seconds) but you can wait however long you like. The **Time** field will increment each second and you can see the total change in RA and Dec in the **dRA** and **dDec** fields.

If you are doing the centering manually you can press the movement buttons. The <u>orientation</u> and <u>operation</u> of these buttons is the same as defined



in the <u>Guide/Slew Page</u>. If you pressed one of the <u>Guide/Center rate</u> <u>buttons</u> then the rate will display in the center of the buttons.

Alternatively, you could use an auto-guider to measure the rate. But you might ask why would you even care to pulse guide if you have an auto-guider? Well, one example is if you are doing imaging with a single CCD camera and you do not have an auto-guider. You could pulse guide to enable you to guide without a guider. The same applies if you have an SBIG camera and are doing Hydrogen Alpha imaging and you cannot find a bright enough guide star through the Hydrogen Alpha filter.

If you are auto-guiding with a CCD camera you just need to press **Stop.** If not you must manually re-center the star visually or with your CCD camera. In either case you will see the following dialog when you press the **Stop** button:

PulseGu	PulseGuide - Measured Rates Results			
	Total Movement (ArcSecs)	Measured Time (Secs)	Rate (ArcSec/Sec)	Use Both Rates
RA	0.0	3.7	0.00000	Use RA Rate
Dec	0	2.8	0.00000	Use Dec Rate
				Cancel

If you don't want to use the rates just press **Cancel**.

Use Both Rates: Automatically fills the **RA Arcsec/sec** and **Dec ArcSec/Sec** fields with the displayed RA and Dec rates, respectively. **Use RA Rate:** Automatically fills the **RA Arcsec/sec** field with the displayed RA rate.

Use RA Rate: Automatically fills the **Dec ArcSec/Sec** field with the displayed Dec rate.

Cancel: Neither rate is used.

Pulse Guiding

When the correct rate has been set pulse guiding will allow you to do unguided CCD exposures for many minutes, even when polar alignment and/or refraction effects the rate that the stars move relative to the motion of the mount.

You activate pulse guiding by pressing the **On** button. Immediately **PulseGuide** will command the mount at precise times with commands sent on the serial port. The real-time rate that **PulseGuide** calculates is displayed just to the left of the **On** and **Off** buttons.

The pictures below are cropped 5-minute ST-10XE images (1.2 arcsec/pixel) taken with a 1200GTO mount and AP155 refractor at 1085 mm focal length. The mount's polar axis was purposely misaligned to show the capabilities of **PulseGuide**. The image on the left shows the extent of the mistracking. Turning pulse guiding on results in a good exposure:



Press the **Off** button to turn off the pulse guider. While pulse guiding is enabled certain features like PEM record are disabled.

Note: While a pulse guiding is on you cannot disconnect from the mount or exit **PulseGuide**.

Realtime Status

When pulse guiding is active there is a variety of real-time information available. The

Pulse Guiding	
RA ArcSec/Sec	.8 🚽 0.77000 On
Dec ArcSec/Sec	.8 ± 0.81353 Off
Pulse Guide Rate:	1.00 x

numbers circled in the picture to the above right are the calculated rates in RA/Dec based on the duration of the movement commands sent to the mount. These are *theoretical* rates.

The **Measure Rate Tool** has this additional information.

Time: Active duration of this pulse guiding session.

dRA: This is the actual measured change in Right Ascension divided by the time active.

Measure Rate Tool				
Start Stop				
Time	912 Secs			
dRA 0.80757 "/S				
dDec 0.81250 "/S				

dDec: This is the actual measured change in Declination divided by the time active.

Even though 6 decimal places are displayed for **dRA** and **dDec** the accuracy of these measurements is typically no more than 1 or 2 decimal places.

Because software timers do not always execute exactly when requested the rates most likely will not exactly match but there is a close-loop algorithm in the software that tries to home in on the desired rate.

The Realtime Status section shows the latest periods of time that the mount moves are active and the total number of commands (pulses) sent to the mount:

– Realtime Status	RA	Dec
Pulse On:	663 mSecs	31 mSecs
Pulse Off:	337 mSecs	969 mSecs
Pulses:	3008 (8.59/sec)	3007 (8.59/sec)

Trouble Shooting

If you are having trouble getting good results:

1. Make sure you have trained $\underline{\mathsf{PEM}}$ on a steady night and have turned PEM on.

2. Try measuring the rate for a longer period (the longer the better). If you measure the rate for less than 7-8 minutes the mount will not go through a complete periodic error cycle.

3. Try changing the Max Pulses per second. If you have a slower CPU or have lots of tasks active try lowering it to 3, then 2, then 1.

4. If the Dec rate in the **Pulse Guiding** area is reversed in sign to the value in **dDec** then you need to <u>swap the N/S buttons</u>. This is shown in the picture below:

PulseGuide for Astro-Physics GTO Series Mounts	
Connect Time Site Park/Rate Guide/Slew Pulse	Guider PG Config PEM/Other TPoint
Pulse Guiding	Measure Rate Tool
RA ArcSec/Sec 0.8 🖬 0.82756 On	Start Stop
Dec ArcSec/Sec 0.8 # 0.83344 0ff	Time 32 Secs
Pulse Guide Rate: 1.00 x	dRA 0.81790 "/S
Realtime Status	dDec 0.83333 "/S
Pulse On: 827 mSecs 27 mSecs	NE N NW
Pulse Off: 173 mSecs 973 mSecs	E W
Pulses: 70 (1.09/sec) 69 (1.08/sec)	SE S SW
RA = 05 53 18.9 Dec = +89 52 03 Side = East LST	HA = +06 00 46

PGConfig Page

You can configure some of the pulse guiding logic's working values here. However you will not usually want to change the default values. The first four edit boxes set values that the pulse guiding logic uses to determine the mount guide rate to use.

PulseGuide for Astro-Physics GTO Ser	ies Mounts
Connect Time Site Park/Rate Gui	ide/Slew Pulse Guider PG Config PEM/Other TPoint
PulseGuide Configuration	
Use 0.25x Guide Rate up to:	2 ArcSec/Sec
Use 0.50x Guide Rate up to: 0	.4 ArcSec/Sec
Use 1x Guide Rate up to: 0	.8 ArcSec/Sec
Use 12X Guide Rate up to: 1	0 ArcSec/Sec
Max Pulses Per Second:	1 Use Defaults
RA = 01 10 38.2 Dec = +52 35 14 Si	de = East LST = 13 07 53 HA = +11 57 15

Use 0.25x Guide Rate up to

If the user-entered guide rate is less than this number in the edit box then the 0.25x guide rate will be used when moving the scope.

Use 0.50x Guide Rate up to

If the user-entered guide rate is less than this number in the edit box then the 0.50x guide rate will be used when moving the scope.

Use 1x Guide Rate up to

If the user-entered guide rate is less than this number in the edit box then the 1x guide rate will be used when moving the scope.

Use 12x Guide Rate up to

If the user-entered guide rate is less than this number in the edit box then the 12x guide rate will be used when moving the scope.

Max Pulses Per Second

This sets the maximum number of pulses in each direction (RA and Dec) that the pulse guiding logic will attempt to send to the mount per second. Each "pulse" is a set of commands. The first command starts movement and is sent at a precise time. The second command, also sent as a precise time, stops it.

Use Defaults

Click this button to reset the defaults of all controls on this page.

PEM/Other Page

Here you can control periodic error management functions, focus positioning, reticle brightness, and mount backlash.

🔶 PulseGuide for Astro-Physics GTO Serie	s Mounts		
Connect Time Site Park/Rate Guide	/Slew Pulse Guider PG Config PEM/Other TPoint		
Periodic Error Management	Focus Control Reticle		
PEM ON PEM OFF	Slow + 2 +		
Last Sent:	C Fast · Reset Pos ·		
PEM Record	Backlash Arc Secs		
PEM Record Stop Timer	Set Dec 0 Backlash		
PEM Timer	Set RA 0 Tests		
RA = 01 58 10.8 Dec = +52 35 14 Side = East LST = 13 55 25 HA = +11 57 15			

Periodic Error Management

PEM ON: Press this button to turn on the mount's periodic error correction logic. Before doing this you should do a **PEM Record** on a night of steady seeing. Once pressed the **Last Sent** edit box will be updated.

PEM OFF: Press this button to turn off the mount's periodic error correction logic. Once pressed the **Last Sent** edit box will be updated.

PEM Record: Press this button to start a PEM record. Typically you will want to wait until a night with relatively steady seeing for your area. Have a CCD camera autoguiding on a relatively bright star (mag 6+) near the meridian and declination 0. Once pressed the timer is activated. Once you are sure the PEM is done (7-8 minutes is adequate) then click the **Stop Timer** button. PEM is ready to use by clicking **PEM ON**.

Focus Control

With this control panel you can control the in and out movement of your focuser. To use this function you must have an electric focus motor plugged into the focuser port on your GTO Control Box. JMI, Meade and others make such a focuser.



First, select the rate, fast or slow then press the + or – button to adjust the focus. Note: The selected rate will override the keypad's rate once one of these buttons is pressed.

Quickly pressing the "+" (or "-") button will send a pulse about 40 milliseconds in length and change the position by 1 unit if in slow mode and 100 units if in fast mode. If you keep pressing the button then additional pulses will be sent. The pulses will accelerate as you keep pressing.

Note: 100 position units in slow mode is NOT necessarily equal to 100 position units in fast mode. That is dependent on the hardware.

You can reset the counter by pressing the "**Reset Pos**" button. Because there is no direct correlation between the rates of the fast and slow modes the position will automatically reset to 0 if you switch between Fast and Slow focusing modes.

Reticle

You can adjust the brightness of an illuminated reticle with this control. First, plug the cord of the reticle into the connector on the GTO Control Panel. Pressing the "+" button will increase reticle brightness. Pressing the "-



"button will reduce brightness. One click of the button will change the brightness by one level up to the maximum or minimum brightness.

Backlash

This command sets the amount of backlash compensation employed each time a servo motor axis reverses direction.

⊢ Ba	acklash	Arc Secs	
	Set Dec	0	Backlash
	Set RA	0	Tests

Set Dec: Clicking this button sets the Dec backlash of the mount.

Set RA: Clicking this button sets the RA backlash of the mount.

Backlash Tests

Click the **Backlash Tests** button to bring up three tests suggested by **Roland Christen** to test the health of your declination axis. Roland posted some tests that you can run on your AP mount to see if it has a potential problem with Dec movement.

IMPORTANT: Before running tests 1 and 2 set the mount's backlash to 0. Also while performing the tests do not try to autoguide.

AP Backlash Tests	
 Test 1 After starting an exposure press test at the 0.5x guide rate. It will complete with the default setting 100 seconds. 	the "Start Test 1" button. Do this take about 90 seconds to gs so try an exposure of at least
Guide Rate 0.50x 💌 Move Time: 10 D	efault 10 secs
Pause Time: 2 D	efault 2 secs Start Test 1
After starting an exposure then p The movements will take about for 25 or 30 seconds. Do one im	press the "Start Test 2" button 21 seconds so set the exposure hage for each of the 3 guide rates.
Move Time: 5 D	efault 5 secs
Pause Time: 1 D	efault 1 sec Start Test 2
Test 3 This test requires you to take th	e cover off the dec motor box to
observe the drive. It sends pulse then an equal number of pulses	to the South.
observe the drive. It sends pulse then an equal number of pulses Guide Rate Cycle I De	efault: Cycle through all 3 rates
observe the drive. It sends pulse then an equal number of pulses Guide Rate Cycle D Pulses: 5 D	efault: 5

Dec Backlash Test 1

Before starting Test 1 set up your camera control program (e.g. MaximDL, CCDOps, etc.) to do a 100 second exposure (but do not autoguide). You can also set up an auto-dark exposure, but make sure that you start the test when the camera control software is exposing the light image.

Test 1 After starting an exposure press the "Start Test 1" button. Do this test at the 0.5x guide rate. It will take about 90 seconds to complete with the default settings so try an exposure of at least 100 seconds.			
Guide Rate	0.50x 💌		
Move Time:	10	Default 10 secs	
Pause Time:	2	Default 2 secs	Start Test 1

Once you start the exposure press the "**Start Test 1**" button. With the default settings (recommended) the entire procedure will take about 90 seconds.

Test 1 will move the scope in this manner: East - pause - West - pause -East to center - North - pause - South pause - North to center.

The stars in the resulting exposure should look something like the image to

the right. The scale might be different but you should see what looks like many plus signs in the image.

If you take the image near Dec=0 the height and width will be about the same. Although not shown in this particular image the East and West points will be slightly brighter than the North/South points. This will make it easy for Roland to establish the orientation of the camera.



Dec Backlash Test 2

You will run Test 2 three times, once for each of the guide rates. Before starting this test set up your camera control program (e.g. MaximDL, CCDOps, etc.) to

Test 2 After starting an exposure then press the "Start Test 2" button The movements will take about 21 seconds so set the exposure for 25 or 30 seconds. Do one image for each of the 3 guide rates.			
Guide Rate	1.00x 💌		
Move Time:	5	Default 5 secs	
Pause Time:	1	Default 1 sec	Start Test 2

do a 25 second exposure but do not try to autoguide. You can also set up an auto-dark exposure, but make sure that you start the test when the camera control coffware is exposing the

the camera control software is exposing the light image.

Start by setting the **Guide Rate** to 1x. Once you start the exposure press the "**Start Test 2**" button. With the default settings (recommended) the entire procedure will take about 16 seconds.

Although the scale might be different, the stars in the resulting exposure should look something like the image shown.

For reference the actual movement in Test 2 is: North+West - South+West - West only (the pause setting) - North+West.



Now you will need to repeat the tests at 0.50x and 0.25x. The star patterns will look similar but smaller because the movement rate is slower. Here are two examples taken with my Traveler:





0.50x:

AFTER RUNNING TESTS 1 AND 2

If you see star patterns different from the above images then crop a bright star in each of the four images and save them as a high-quality JPEG. Please make sure to "stretch" each image appropriately so that it is not too dim or overexposed. If you do not know how to stretch and create a jpeg then save the cropped image in FITS format.

Then send the 4 files (preferably zipped to save bandwidth) to Roland at chris1011@aol.com.

After submitting these tests AP will advise you if anything appears anomalous and if so what can be done about it.

Dec Test 3

This test moves the declination motor at regular intervals to check that the gears move properly.

To do this test you will need to remove the cover from the declination motor

Test 3			
This test requires you to take the cover off the dec motor box to observe the drive. It sends pulses 2 seconds apart ito the North then an equal number of pulses to the South.			
Guide Rate Cy	vole 💌 Defa	ult: Cycle thro	ugh all 3 rates
Pulses:	5 Defa	ult: 5	
Pulse Duration:	133 Defa	ult: 133 mSec	s Start Test 3

housing (contact AstroPhysics for directions if you need).

The **Guide Rate** combo-box has 4 choices: **0.25x**, **0.50x**, **1.00x**, and **Cycle**. You can choose a specific rate or **Cycle** to have PulseGuide repeat the test at each rate.

While watching the uncovered declination gears click the **Start Test 3** button. PulseGuide will send 5 pulses spaced 2 seconds apart (or however many you entered in the **Pulses** edit box). Each pulse will be of the same duration – that which you enter in the **Pulse Duration** edit box. 133 milliseconds is the default. Watch carefully to make sure the pulses look evenly timed and that the fastest moving gear moves equally each time.

Once all pulses have been sent in one direction, an equal number of pulses are sent in the reverse direction. It is normal on reversal of direction that there is a slight delay in movement because of backlash. If this happens you may wish to increase the pulse count.

If you see erratic movement please contact AstroPhysics for instructions.

TPoint Page

You can use the simple two-step procedure in this page to resynchronize your mount to your <u>Software Bisque</u> <u>TPoint</u> model if you accidentally move your scope by hand.

TPoint Resynchronization – Step 1

First, if you moved your scope by hand, try to reorient it to where it should be or <u>do an unpark from one of the AP park positions</u>. Then connect in TheSky and slew to a reasonably bright star. If the TPoint model is synched properly to the mount then the star will be near the center of the field (using a CCD camera is recommended).

PulseGuide for Astro-Physics GTO Series Mount	ts
Connect Time Site Park/Rate Guide/Slew	Pulse Guider PG Config PEM/Other TPoint
You can use this Two-Step procedure to resynchronize	your mount to your TPoint Model in TheSky.
Although not necessary if you follow the recommended the two steps to resync if you have accidentally or purp	restart procedure for the mount you can use osely moved the OTA by hand.
Step 1	Step 2
With Software Bisque's TheSky connected to your mount and your TPoint model active issue a slew to a medium-bright star. Once the slew is complete press the Get RA/DEC button below.	Center the star in the eyepiece or with your CCD camera. Once centered press the Reset RA//DEC button below. You may need to repeat steps 1 and 2 if a long period of time elapses between Step 1 and 2.
Get RA/DEC DEC:	Reset RA/DEC
RA = 01 35 47.1 Dec = +52 35 14 Side = East	LST = 13 33 02 HA = +11 57 15

If the star is not centered then press the **Get RA/DEC** button. *PulseGuide* will get the current coordinates from the mount then display them in the **RA** and **DEC** read-only edit boxes. This will also enable the **Reset RA/DEC** button as shown in the next figure.

PulseGuide for Astro-Physics GTO Series Mount	ts 📃 🛛 🗙
Connect Time Site Park/Rate Guide/Slew You can use this Two-Step procedure to resynchronize Although not necessary if you follow the recommended the two steps to resync if you have accidentally or purp Step 1 With Software Bisque's TheSky connected to your mount and your TPoint model active issue a slew to a medium-bright star. Once the slew is complete press the Get RA/DEC button below. RA: 01:36:16.3	Pulse Guider PG Config PEM/Other TPoint your mount to your TPoint Model in TheSky. restart procedure for the mount you can use osely moved the OTA by hand. Step 2 Center the star in the eyepiece or with your CCD camera. Once centered press the Reset RA//DEC button below. You may need to repeat steps 1 and 2 if a long period of time elapses between Step 1 and 2.
DEC: 1 + 52 33.14 RA = 01 36 21.4 Dec = +52 35 14 Side = East	LST = 13 33 36 HA = +11 57 15

TPoint Resynchronization – Step 2

Now using the buttons, or manually moving the scope, center the star that you previously slewed to in the last step. This of course may change the RA/DEC of the mount but when you press the **Reset RA/DEC** button the mount is then sent updated the coordinates (coordinates that TPoint issued to bring the star to the center).

If a long period of time elapses between steps 1 and 2, you may need to repeat the procedure.

Troubleshooting

PulseGuide won't connect and I know the COM Port is right.

Make sure you have closed the serial connection in any planetarium applications you might be running. Make sure you don't have another instance of PulseGuide running and connected to that serial port.

Appendix A – ASTRO-PHYSICS COMMAND PROTOCOL FOR GTO MOUNTS (Version "D" or "KD")

Commands effective: 05-07-01 Text modified: 09-24-01

These are the commands associated with version D or KD of the ROM chip in the GTO Control Box. All chips marked C or KC include all commands listed below except Command: :pS#

You can check the version of your chip by opening the cover of the control box. If your chip is not dated at all, it was probably programmed prior to July 1999 and is an early version. The chip versions beginning with "K" are for the 400GTO and 600EGTO mounts shipped after 02-16-00.

These commands are similar to the Meade LX200 protocol:

Command: :Sr HH:MM:SS# or :Sr HH:MM:SS.S# Response: "1"

Defines the commanded Right Ascension, RA. Command may be issued in long or short format regardless of whether long format has been selected. RA specified as DD*MM:SS will also be interpreted properly if greater precision is required, but this is not typically how RA is expressed. This command automatically selects RA-DEC mode. Move and calibrate commands operate on the most recently defined RA if in RA-DEC mode.

Command: :Sd sDD*MM# or :Sd sDD*MM:SS# Response: "1"

Defines the commanded Declination, DEC. Command may be issued in long or short format regardless of whether long format has been selected. This command automatically selects RA-DEC mode. Move and calibrate commands operate on the most recently defined DEC if in RA-DEC mode.

Command: :Sa sDD*MM# or :Sa sDD*MM:SS# Response: "1"

Defines the commanded Altitude, ALT. Command may be issued in long or short format regardless of whether long format has been selected. Move and calibrate commands operate on the most recently defined ALT. This command automatically selects ALT-AZ mode, however tracking rate is unaffected.

Command: :Sz sDD*MM# or :Sz sDD*MM:SS# Response: "1"

Defines the commanded Azimuth, AZ. Command may be issued in long or short format regardless of whether long format has been selected. Move and calibrate commands operate on the most recently defined DEC. This command automatically selects ALT-AZ mode, however tracking rate is unaffected.

Command: :SG HH# or :SG HH:MM.M# or :SG HH:MM:SS# Response: "1"

Sets the offset from Greenwich mean time. Command may be issued in any format regardless of whether long format has been selected. Although any 24-hour format is acceptable, only the hours field is typically of interest.

Command: :Sg DDD*MM# or :Sg DDD*MM:SS# Response: "1"

Sets the current longitude. Command may be issued in long or short format regardless of whether long format has been selected.

Command: :St sDD*MM# or :St sDD*MM:SS Response: "1"

Sets the current latitude. Command may be issued in long or short format regardless of whether long format selected.

Command: :SL HH:MM:SS# Response: "1"

Sets the current local time. Command may be issued in long or short format regardless of whether long format selected.

Command: :SC MM/DD/YY# Response 16 spaces followed by "#", followed by 16 spaces, followed by "#"

Sets the current date. Note that year fields equal to or larger than 97 are assumed to be 20th century, Year 97 are assumed to be 21st century.

Command: :GG# Response: HH:MM.M#

or HH:MM:SS.S# if long format

Gets the offset from Greenwich mean time. Although typically only hours field is of interest, the return value will standard 24 hour format.

Command: :Gg# Response: +DDD*MM#

or +DDD*MM:SS# if long format

Gets the current longitude.

Command: :Gt# Response: sDD*MM#

or sDD*MM:SS# if long format

Gets the current latitude.

Command: :GL# Response: HH:MM.M# or HH:MM:SS.S# if long format Gets the current local time in 24 hr. format.

Command: :GS# Response: HH:MM.M# or HH:MM:SS.S# if long format

Gets the current sidereal time in 24 hr. format.

Command: :GR# Response: HH:MM.M# or HH:MM:SS.S# if long format

Gets the current Right Ascension.

Command: :GD# Response: sDD*MM# or sDD*MM:S3

or sDD*MM:SS# if long format

Gets the current Declination.

Command: :GA# Response: sDD*MM#

or sDD*MM:SS# if long format

Gets the current Altitude.

Command: :GZ# Response: sDD*MM#

or sDD*MM:SS# if long format

Gets the current Azimuth.

Command: :CM# Response: "Coordinates matched. #" (there are 5 spaces between "Coordinates" and "matched", and 8 trailing spaces before the "#", the total response length is 32 character plus the "#".

Calibrate mount. Current Right Ascension and Declination become the commanded Right Ascension and Declination respectively if in RA-DEC mode. If in ALT-AZ mode, then the commanded Altitude and Azimuth become the current. This command assumes that the mount has been manually positioned on the proper pier side for the calibration object. This command is ignored if slewing is in progress. This command should be used for initial calibration. It should not be used after the mount has been tracking unless it is known that it has not tracked across the meridian.

Command: :Mn# :Ms# :Me# :Mw# Response: (none)

Command motion in the direction specified (n=north, s=south, e=east, w=west) the currently selected guide or centering rate. Motion will continue until a quit command is issued.

Command: :MS#

Response: "0" if command accepted, (none) if command not accepted, "1Object is below horizon #" if the horizon check is turned on, and the desired object is below 0 degrees altitude. (8 trailing spaces before "#", 32 total characters plus "#")

Slew to the most recently defined RA and DEC coordinates in RA-DEC mode, or most recently define ALT and AZ coordinates in ALT-AZ mode. Slewing is performed at the currently selected slew rate. If the horizon check is turned on, and the object is below the horizon, this will be stated, and no slewing will occur.

Command: :Qn# :Qs# :Qe# :Qw# Response: (none)

Stop motion in the specified axis. Note that :Qn# is identical to :Qs#, and :Qe# is identical to :Qw#. Motion is terminated only if it was not started by a slew (:MS#) command.

Command: :Q# Response: (none)

Motion in both axis is stopped, regardless of how the motion was invoked.

Command: :U# Response: (none)

Select long format, valid only for the communication port through which this command is issued, ports are controlled independently. Unlike the Meade definition, though, once long format has been selected it cannot be deselected without powering down the unit. Only the first occurrence of :U# acts upon the port in question. Long format only defines the format of the return strings, Input data (using the set command) will be recognized in any format whether or not long format has been selected.

Command: :B+# :B-# Response: (none)

Incrementally increases (B+) or decreases (B-) reticle brightness. Command to be sent over RS-232 each time a button is pressed to increase or decrease brightness. When the brightness is at the maximum, subsequent :B+# commands are ignored. When the brightness is at the minimum, subsequent :B-# commands are ignored. On power up, the brightness is at the minimum (off). The Meade commands :B0# :B1# :B2# :B3# are not implemented.

PulseGuider v1.26 User Guide and Manual v1.04 – Copyright © 2003/4 Ray Gralak

Command: :F+# :F-# :FF# :FS# :FQ#

Response: (none)

Advances (F+) or retracts (F-) focus adjust motor on the eyepiece. F+ or F- commands commence adjustment and :FQ# stops it. This works the same way the N-S-E-W keypad works (it may even be an operating mode of the same keys). If :FS# has been issued previously, then the focus adjustment will be slow. If the :FF# command has been issued, then the adjustment will be fast. If neither FF nor FS is specified, the powerup default of FS is assumed.

Command: :RG# :RG0# :RG1# :RG2# Response: (none)

Selects guide rate for the N-S-E-W buttons. Optionally selects 0.25x (:RG0#), 0.5x (:RG1#), or 1.0x (:RG2#). If no index is provided (:RG#), the previously selected guide rate will be used, else the power up default of 0.5x will be assumed by the motor drive. The indexes are extensions of the Meade protocol.

Command: :RC# :RC0#	:RC1#	:RC2#	:RC3#
Response: (none)			

Selects centering rate for the N-S-E-W buttons. Optionally selects a rate of 12x (:RC0#), 64x (:RC1#), 600x (:RC2#), or 1200x (:RC3#). If no index is provided (:RC#), then the previously selected speed will be used, else the power up default of 64x will be assumed by the motor drive. The indexes are extensions of the Meade protocol.

Command: :RS# :RS0# :RS1# :RS2# Response: (none)

Selects the slew speed used by the telescope move functions. This command has no effect on the use of the N-S-E-W buttons (therefore, :RS# has no effect). The default slew speed is 1200x. Slewing can be done at 1200x (:RS2#), 900x (:RS1#), or 600x (:RS0#). The indexes are extensions of the Meade protocol.

Meade commands:

Command: # Response: (none)

Sending a # clears the input buffer. Advisable to do this before sending the very first command on power up.

Command: :RT0# :RT1# :RT2# :RT9# Response: (none)

This command selects the tracking rate. It selects lunar (:RT0#), solar (:RT1#), sidereal (:RT2#), or zero (:RT9#). The sidereal rate is assumed as a default by the motor drive if nothing is specified. This command has no effect on the use of the N-S-E-W buttons. This command is not in the Meade manual. Zero tracking rate is useful in ALT-AZ mode.

Command: :NS# Response: (none)

This command swaps the functions of the north and south buttons. Subsequent commands :Mn# and :Ms# are affected. This command is not in the Meade manual.

Command: :EW# Response: (none)

This command swaps the functions of the east and west buttons. Subsequent commands :Me# and :Mw# are affected. This command is not in the Meade manual.

PulseGuider v1.26 User Guide and Manual v1.04 – Copyright © 2003/4 Ray Gralak

Command: :p# :pR# :pP# Response: (none)

This command either invokes PEM record mode (:pR#), invokes PEM playback mode (:pP#), or turns playback off (:p#). The record function will remain active for one full revolution of the worm gear and cannot be terminated. If :p# or :pP# is received during record, it will be ignored. The time required for a record cycle depends upon which mount is used and how much correction is applied. Commands to slew will be ignored during record. Commands to select centering speed will become active only after the record cycle has been completed. When playback is selected, it remains active until turned off. Playback is also temporarily turned off when a command to slew is issued or any of the N-S-E-W buttons are pressed. It is automatically reinvoked when the commanded position has been reached and none of the N-S-E-W buttons are pressed. This command is not in the Meade manual.

Command: :Bd DD*MM:SS# :Br DD*MM:SS# Response: "1"

This command sets the amount of backlash compensation employed each time a servo motor axis reverses direction. Bd sets the backlash of the DEC axis, Br sets the backlash of the RA axis. Resolution of the backlash is in arc seconds. Typically, the degrees and minutes fields are zero to specify the amount of backlash only in seconds. Values of backlash above 00*54:36 may be truncated, depending upon which mount is used (this is a ridiculously large value, typical values should be well under 00*01:00). The default DEC backlash is 00*00:00, the default RA backlash is 00:00:15 (same as 00*03:50). Backlash in either axis will be properly interpreted whether expressed as DD*MM:SS or HH:MM:SS. This command is not in the Meade manual.

Command: :ho# :ha# Response: (none)

This command turns on (:ho#) and off (:hq#) the horizon check. The horizon check, when turned on, is performed when a "go-to" (or :MS#) is issued. If the coordinates define a location below zero degrees altitude, then the string "10bject is below horizon. #" is returned instead of "0". No compensation of coordinates for atmospheric refraction is made. On power-up, the horizon check is off since it is currently performed in the handheld controller, Digital Sky Voice, and Software Bisque's TheSky.

Command: :de# :dn# Response: (none)

This command invokes the data feed through function between COM 1 and the handheld controller. The purpose is to allow software and database updates to the handheld controller, through the servo drive, without special connectors. For code downloads, :de# is used to provide transparent communications between COM 1 and the handheld unit with even parity. For database downloads, :dn# is used to provide transparent communications with no parity. Once either command is issued, normal operation (or parity change) can only be resumed by powering down the servo drive. COM 2 cannot be used in the transparent mode. Once the pound sign of the command has been received by the servo drive, all subsequent bytes received from COM 1 or the handheld are reflected to the other. Data received on COM 2 is ignored, and no data is transmitted from COM 2.

Command: :CMR#

Response: "Coordinates matched.

#" (there are 5 spaces between "Coordinates" and "matched", and 8 trailing spaces before the "#", response length is 32 character plus the "#". the total

This command performs a function very similar to the :CM# command with one exception. It does not assume that the user has manually positioned the mount on the proper pier side for the object in view. It assumes that the pier side has not changed since the most recent :CM# or :MS# commands. It allows re-calibration on known coordinates even if the mount has tracked across the meridian. This command should not be used to perform the initial calibration. This command is ignored if slewing is in progress.

Command: :KA# Response: (none) This command invokes the parked mode. The tracking stops and the motors are de-energized when slewing has completed. The mount will remain parked, even if power is cycled, until a move, quit, calibrate, or park-off command is issued.

Command: :PO# Response: (none)

Park-off. This command un-parks the mount and also restores calibration. To restore proper calibration, the mount must receive date and time (:SC dd/mm/yy# and :SL hh:mm:ss#) prior to receiving the Park-off command. If park-off is received when the mount is not actually parked, calibration error will be introduced. A :CM# command can be used, however, to establish accurate calibration.

Command: :V# Response: (current servo controller software version number)

This command returns the current servo controller software version (followed by "#"). Software versions prior to B do not return anything since the version command is introduced in version B.

Command: :pS# Response: "East#" or "West#"

This command returns the side of the pier on which the telescope is currently positioned. It is useful for remote observatories where it is not possible for the viewer to see the mount. Initially, the mount must be manually positioned on the proper pier side for the calibration object and calibrated using the :CM# command. The correct pier side will be returned after subsequent move, recalibrate, park and unpark commands.

RS-232 Port Settings:

Baud Rate:	9600	Parity:	
		none	
Data bits:	8		
Flow Control:		none or Xon/Xoff	
Start Bits:		1 Stop Bits:	1

Appendix B – AP Commands by Category

Right Ascension	
Set (to Move) Get	Sr GR
Declination Set(to Move) Get	Sd GD
Altitude Set(to Move) Get	Sa GA
Azimuth Set(to Move) Get	Sz GZ
Move (slew)	MS
Offset from Green Set Get	wich Mean Time SG GG
Mount Longitude Set Get	Sg Gg
Mount Latitude Set Get	St Gt
Local Time Set Get	SL GL
Current Date Set Get	SC N/A
Get Sidereal Time Set Get	N/A GS

Motion

North	Mn
South	Ms
East	Me
West	Mw

Stop Motion

North	Qn
South	Qs
East	Qe
West	Qw
Stop ALL	Q

Select Long Format U

Reticle Brightness

Increase	B+
Decrease	В-

Focus

Start Advance	F+
Start Retract	F-
Slow	FS
Fast	FF
Stop Focus	FS

Guide Rate

0.25x	RG0
0.50x	RG1
1.00x	RG2

Center Rate

12X	RC0
64X	RC1
600X	RC2
1200X	RC3

Slew Rate

600X	RS0
900X	RS1
1200X	RS2

Track	king Rate	
	Lunar Solar Sidereal Zero	RTO RT1 RT2 RT9
Swap	o Buttons	
	North/South East/West	NS EW
Perio	dic Error Manag	ement
	Record Playback Playback off	pR pP p
Back	lash	
	Dec RA	Bd Br
Horizon check		
	On Off	ho hq
Data	feed	
	Even Parity No Parity	de dn
Calib	rate Mount	
	Pier correct Pier-side same	CM CMR
Park		
	Park Mount Unpark	KA PO
Versi	on	V
Pier	Side	pS

Appendix C – AP Park Positions

Park Position 1: Scope is level and pointing North. Scope is on the west side of the mount.

Park Position 2: Scope is level and pointing East. RA Axis vertical and Dec = 0.

Park Position 3: Scope is pointing to pole. RA axis is vertical, Dec = 90.





